

Thermal Printer

μTP-58E (Panel Type)

μTP-58EB (Bulk Type)

Instruction Manual

INTRODUCTION

Thank you very much for your continued favor. Please read this manual attentively to let this equipment serve you for as long as possible. Keep this manual carefully.

SAFETY PRECAUTIONS

The following symbols are used in this Instruction Manual in order to make use of the printer properly and prevent the printer from being damaged.

Follow the instructions marked with the symbol.

	WARNING	Failure to follow the guidelines marked with this symbol could result in severe personal injury or death.
	CAUTION	Failure to follow the guidelines marked with this symbol could result in minor personal injury or product and/or peripheral damage.

Symbol Examples

- The symbol indicates caution(including danger and warning). The example on the left indicates warning or caution.
- The symbol indicates prohibition. The example on the left means prohibition of disassembling.
- The symbol indicates requirement or what must be done. The example on the left means "pull the power plug out of the outlet."

WARNING

- DO NOT use an AC adapter other than that which is specified. Doing so may cause fire leading to serious accidents.
- DO NOT bend the power cable forcibly, or place heavy object on the cable because it might damage the cable and cause fire or electric shock.If the power cable is damaged, discontinue use and replace it immediately.
- Never disassemble the printer and the AC adapter. Failure to follow this instruction may cause overheating or burning of the printer or the AC adapter, or an electric shock, which may lead to fires or accidents.

CAUTION

- DO NOT drop any metallic objects or liquids, such as water or coffee, into the printer.
- Never use the printer in a place of extreme humidity or any place where it can possibly be splashed by any liquids. If any liquids get into the printer, it could lead to fire, electric shock, or other serious accidents.
- Never touch the thermal head immediately after printing because it becomes very hot. Make sure that the thermal head is cool before setting papers or cleaning the thermal head.
- Be sure to hold the connector part of the power cable or interface cable when disconnecting the cable. Pulling on the cable portion may cause it to fray and break.
- Power OFF the printer in any of the following cases:
 - The printer does not recover from an error.
 - Smoke, strange noise or smells erupt from the printer.
 - A piece of metal or any liquid touches the internal parts or slot of the printer.
 Using the printer in any manner other than for which it was designed may cause accidents or fire.

1 . OPERATING PRECAUTIONS

Observe the following for safe and trouble-free operation:

Notes on use

- Do not drop or hit the printer.
- Turn off the power switch, and keep the AC adapter removed from the receptacle when the equipment is not used.

Notes on treatment of thermal papers

- Store the papers in a dry, cool and dark place.
- Do not rub the papers with hard substance.
- Keep the papers away from organic solvent.
- Do not let the papers touched with vinyl chloride film, eraser or adhesive tapes for hours.
- Do not put the papers on diazo print or wet copy that is just copied.
- Use dedicated thermal papers only.

Notes on installation

- Install the printer on a stable surface.
- Avoid such places with:
 - Unstable surface, Strong vibration,
 - Direct sunlight, Full of dust, Corrosive gas,
 - Excessively high or low temperature

2 . PREPARATION

2.1 Unpacking

Check whether a complete set is present:

- Main body 1 unit
- Thermal papers 1 roll
- Instruction Manual 1 volume


μTP-58E (Panel Type) includes next ones, too.

- Main body fitting 1 unit
- Fitting mounting screw 2 pieces
- Fitting spacer 0.2mm thick 1 sheet
- Fitting spacer 0.5mm thick 1 sheet
- Fitting spacer 1.0mm thick 1 sheet


Orders for thermal papers will receive prompt attention by our company.

2.2 Components/part names


μTP-58E (Panel Type)



μTP-58EB (Bulk Type)




Back face



2.3 How to install the main body fitting

Use the spacers as much as you need.



Use the spacers depending on the fitting panel thick like next table. If not, the body will be deformed, and it will be hard to open the paper cover, and the printing quality will be down. (When the fitting panel thick is over 2.2mm, it will be hard to fit the screws.)

Panel thick	Spacer thick	Panel thick	Spacer thick
1.0	None	1.7 ~ 1.8	0.5 and 0.2
1.2	0.2	2.0	1.0
1.5 ~ 1.6	0.5	2.2	1.0 and 0.2

(unit:mm)

The screw torque is 49cN·m(5kgf·cm).

3 . OPERATION

3.1 Connecting AC adapter


Insert the DC plug of the AC adapter into the DC socket of the main body.
Insert the AC plug of the AC adapter into the receptacle.

[Attention!]

Do not touch the tip end of the DC plug. When disconnecting the AC adapter, disconnect the AC plug from the receptacle and then DC plug.

3.2 Setting papers

Opening paper cover




Setting papers

Press the paper cover open button, and open the paper cover.

Set a paper roll as shown in the figure.

Close the paper cover by pressing the both end of the cover, with the tip end of the paper emerging from the printer.



3.3 Maintenance

Wipe off the soiling on the printer surface with a dry soft cloth or a cloth with a weak neutral detergent. After that, wipe the printer with a dry cloth.

[Attention!]

- Do not use volatile chemical as thinner or benzene.
- Do not get printer's inside wet with water.

3.4 Test print

In the test print mode, characters printable with the printer are output(ANK,Kanji). Turning power ON with FEED_IN signal kept low triggers the test print.

3.5 Hex dump

In hex dump mode, computer data is output in hexadecimal numbers and characters. Set the dip switch No.7 on, No.8 off, and power on, then enter hex dump mode.

3.6 Function set

Printer functions can be set with the dip switches.

The indicates shipment mode.

No.	Function	OFF	ON
1 ~ 4	Interface	See table 1	
5	Bit len	8BIT	7BIT
6	Flow	RTS/CTS	Xon/Xoff
7 ~ 8	Command	See table 2	
9	Direction	Upright	Inverted
0	Test pin	Normal Mode	Prohibition

Table 1. Interface mode

Method	Baud	Parity	1	2	3	4
Serial	38400	None	x	x	x	x
				x	x	x
			x		x	x
					x	x
	2400	Odd	x	x		x
				x		x
			x			x
				x		x
	38400	Even	x		x	
					x	
			x	x		
				x		
Parallel	-	-				

Table 2. Command mode

Mode	7	8
Mode1(20 colm. μTP-5820 compatible)		
Mode2(24 colm. μTP-5824 compatible)	x	
Mode3(32 colm. ESC/POS conformed)	x	x
Hex dump mode		x

(x : OFF : ON)

You can check the setting functions by Test Print.

UTP-58E TEST PRINT	
[VX.XX] XXXX/XX/XX	
INTERFACE	= PARALLEL
BAUD RATE	= 9600bps
PARITY	= NON
BIT LENGTH	= 8BIT
FLOW CONTROL	= RTS/CTS
COMMAND MODE	= MODE 3
UPRIGHT/INVERT	= UPRIGHT

3.7 Connecting the Printer


- Select the correct interface cable for the type of computer.
- Use a flat cable no more than 50 centimeters long. (We will prepare the option cable.)

4 . SPECIFICATIONS

4.1 Connector pin layout

- Interface connector pin layout


Connector used: XG4A-4032(Omron)



(Name indicates Active Low.)

No.	Signal name	Direc	Function
1	STROBE	In	Data capture
2 ~ 9	DATA0 ~ 7	In	High:1,Low:0
10	ACK	Out	Acknowledge
11	BUSY	Out	Busy to read
12	PE	Out	Paper empty
13	SEL OUT	Out	Online High
14	ERROR	Out	Error
15	RESET	In	Reset
16	TxD	Out	232C Data send
17	RxD	In	232C Data rec
18	RTS	Out	232C Request
19	CTS	In	232C Clear
20	N.C	-	N.C
21	N.C	-	N.C
22	GND	-	GND
23	GND	-	GND
24	N.C	-	N.C
25	FEED_IN	In	Feed signal
26	GND	-	GND
27	SEL_LED+	Out	SEL LED on +
28	SEL_LED-	Out	SEL LED on -
29 ~ 34	V+	-	Power (+)
35 ~ 40	V-	-	Power (-)

-Connect to all the No.29 ~ 34 and No.35 ~ 40 pins, when you supply the power into V+ and V- pins. (To avoid voltage drops.)



- DC socket pin layout

Connector used: HEC0470-01-630(Hosiden)
Polarity: Center plus

No.	Signal name	Direc	Function
1	DC+8.7V	-	Power(+)
2	GND	-	Power(-)

-You can also supply the power through the interface connector pins, instead of DC socket pins.

4.2 General specifications

Command mode:

- Mode1 (μTP-5820 compatible)
- Mode2 (μTP-5824 compatible)
- Mode3 (ESC/POS conformed)

Print mode: Thermal line dot print

Data entry:

- When parallel
 - Data input: Eight-bit parallel
 - Handshake: STROBE, BUSY and ACK

When serial

- Data input: RS-232C (2400bps~38400bps)
- Data control: RTS/CTS, Xon/Xoff

Max. printing speed: 20 mm/s max. (when 5V)
50 mm/s max. (when 9V)

Paper width: 58 mm

- Printing width: Mode1 34.75mm
- Mode2 41.75mm
- Mode3 48mm

-Printed in center of paper.

Power supply:

- By the interface connector
 - 5VDC ~ 9VDC, 3A

By the DC socket

- AC adapter dedicated to the printer (option)

- Product No.: BLS-120W
- Input: 100~240VAC (50/60Hz)
- Output: 9.0VDC, 3.0A

AC code of AC adapter (option)

- Product No.: ACS-100J (for Japan)
- ACS-100U (for U.S.A)
- ACS-100G (for Europe)

Outer dimensions (W x H x D excluding projections)

μTP-58E (Panel Type)

101mm x 116mm x 61mm

μTP-58EB (Bulk Type)

95mm x 110mm x 61mm

Mass: (Excluding AC adapter and roll paper)

μTP-58E (Panel Type) Approx. 230g

μTP-58EB (Bulk Type) Approx. 230g

Operating environment

Temperature: 0 to +50

Humidity: 30 to 80%RH (non-condensing)

Storage environment

Temperature: -20 to +60

Humidity: 20 to 85%RH (non-condensing)

Thermal papers used

Product No.: P-58-30 (10rolls per box)

Paper width : 58mm

Outer diameter of roll paper : 50mm

Receive buffer: 4096 bytes



SANEI ELECTRIC INC.

Head office
Taisou Ikebukuro Building 5F, 2-61-1 Ikebukuro,
Toshima-ku, Tokyo, 171-0014, Japan
Phone: +81-3-3986-0646(representative)
Fax: +81-3-3988-5876

Information in this document is subject to change without prior notice due to remodeling.

(10.2010)